

OpenGarage Firmware 1.0.4 API Document

Dec 30, 2016

1. Overview

This document describes OpenGarage (OG) Firmware 1.0.4 API.

- In the following, when device key is required, it is referred to as **dkey=xxx**. The default device key at factory reset settings is opendoor.
- The device IP address is referred to as **devip**
- For most commands, parameters are optional and the order of parameters does not matter.
- **Return values** are all formatted in JSON, for example: **{"result":1}**
- **Return error code:**
 - 1 Success
 - 2 Unauthorized (e.g. missing device key or device key is incorrect)
 - 3 Mismatch (e.g. new device key and confirmation key do not match)
 - 16 Data Missing (e.g. missing required parameters)
 - 17 Out of Range (e.g. value exceeds the acceptable range)
 - 18 Data Format Error (e.g. provided data does not match required format)
 - 32 Page Not Found (e.g. page not found or requested file missing)
 - 48 Not Permitted (e.g. cannot operate on the requested station)
 - 64 Upload failed (e.g. OTA firmware update failed)

2. Get Controller Variables: <http://devip/jc>

Returned JSON variables:

- **dist:** distance sensor value (unit: cm)
- **door:** door status (binary, 1 means open, 0 means closed)
- **rcnt:** read count (increments every time distance sensor is read)
- **fwv:** firmware version
- **name:** device name
- **mac:** MAC address
- **cid:** WiFi chip ID

3. Change Controller Variables:

<http://devip/cc?dkey=xxx&click=1&reboot=1>

Parameters:

- **dkey:** device key (factory default device key is opendoor)
- **click:** trigger relay click (the timing is set by the **cdt** option)
- **reboot:** reboot device

Examples:

- <http://devip/cc?dkey=xxx&click=1> trigger relay click
- <http://devip/cc?dkey=xxx&reboot=1> reboot device

4. Get Options: <http://devip/jo>

Returned JSON variables: (factory default values indicated in bold font)

- fwv: firmware version (read-only)
- acc: access mode (**0: direct IP only**; 1: direct + cloud; 2: cloud only)
- mnt: mounting type (**0: ceiling mount**; 1: side mount)
- dth: distance threshold (unit: cm, default **50**)
- riv: read interval (unit: second, default **3**)
- alm: alarm (0: no alarm; **1: 5-second alarm**; 2: 10-second alarm)
- http: http port (default **80**)
- cdt: click delay time (unit: ms, default **1000**)
- auth: cloud authorization token
- name: device name (default "**My OpenGarage**")

5. Change Options:

<http://devip/co?dkey=xxx&nkey=xxx&ckey=xxx&opname=opvalue...>

Options:

- For the list of option names (opnames), refer to Section 4 above.
- Some option are cannot be modified through the /co command: including fwv, dkey. These are either read-only options, or should be set in a different way.
- To change device key, use the nkey and ckey pairs (new key, and confirm key).

Examples:

- [devip/cc?dkey=xxx&nkey=abc&ckey=abc](#) set device key to 'abc'
- [devip/cc?dkey=xxx&dth=75](#) set distance threshold to 75cm
- [devip/cc?dkey=xxx&cdt=500](#) set click delay time to 500ms
- [devip/cc?dkey=xxx&auth=0123456789abcdef](#) set cloud authorization token
- [devip/cc?dkey=xxx&http=8080&riv=5](#) set http port to 8080 and read interval to 5 seconds

6. Get Log Data: <http://devip/jl>

Returned JSON variables:

- name: device name
- time: device time (UTC epoch time)
- logs: log data - an array of log entries, each entry in the form of [time_stamp, door_status, distance_value]